

Sugar Paste Warmers

SugarSMAC carries the XP3000 Sugar Warmer. This advanced sugar paste warmer comes with pre-set temperatures that are ideally suited to warm all the SugarSMAC sugaring paste varieties, as well as a pre-heat setting.

Features: 4 selectable pre-set temperatures. These temperatures roughly correspond with SugarSMAC pastes as follows (from bottom indicator light to the top):

- | | |
|---------------------------------------|-------------------------------|
| Setting 1: Lush and Ultra-Lush | Setting 3: Firm |
| Setting 2: Classic (default) | Setting 4: Strip-Paste |

Operating Instruction Summary (complete instructions come with each warmer)

1. When the warmer is plugged in it will turn on and automatically go into pre-heat mode. When the pre-heat is done, the warmer will default to setting 2 (Classic).
2. Pre-heating may be skipped by pressing the circular selector button. To re-enter pre-heat mode, hold down the selector button for 2 seconds.
3. To select a pre-set temperature, press the selector button: 1 time for Lush/Ultra-Lush, 2 times for Classic (default), 3 times for Firm, and 4 times for Strip-Paste.
4. Once the warmer has raised the temperature to the selected pre-set, there will be a short beep sound and the indicator light will flash.
5. Although the warmer may have reached the selected pre-set temperature, all the paste in a tub may not have been evenly heated. It is recommended to warm the paste for about an hour to achieve even heat distribution. **Always leave the lid on during heating to help avoid contamination and for more even heating.**
6. It is recommended to always leave the warmer on with the paste in the warmer. When it is time to start a new tub or different variety of paste, hold down the selector button for 2 seconds to re-enter the pre-heat mode.
7. To turn off the warmer either unplug the power adaptor or push the selector button until all the lights go off. Pressing the selector button in this way will put the warmer in standby mode and is indicated by the 4 LEDs flashing every 5 seconds.

